

# HEATING BOILER LOG



**LOG THIS INFORMATION WEEKLY**

| MONTH     | SAFETY/RELIEF VALVE<br>WATER |   |   |   |   | WATER COLUMN GAUGE |   |   |   |   | LOW WATER FUEL<br>CUT-OFF |   |   |   |   | CIRCULATING PUMP/RETURN STAMP<br>AND SYSTEM (HOT/HEAT) |   |   |   |   | BURNER OPERATION |   |   |   |   |
|-----------|------------------------------|---|---|---|---|--------------------|---|---|---|---|---------------------------|---|---|---|---|--|---|---|---|---|------------------|---|---|---|---|
|           | 1                            | 2 | 3 | 4 | 5 | 1                  | 2 | 3 | 4 | 5 | 1                         | 2 | 3 | 4 | 5 | 1  | 2 | 3 | 4 | 5 | 1                | 2 | 3 | 4 | 5 |
| JANUARY   |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| FEBRUARY  |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| MARCH     |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| APRIL     |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| MAY       |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| JUNE      |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| JULY      |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| AUGUST    |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| SEPTEMBER |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| OCTOBER   |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| NOVEMBER  |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |
| DECEMBER  |                              |   |   |   |   |                    |   |   |   |   |                           |   |   |   |   |  |   |   |   |   |                  |   |   |   |   |

**TEST INSTRUCTIONS**

**SAFETY/RELIEF VALVE**—pull try-lever to full open position with pressure on boiler. Release lever to allow valve to snap closed. Caution—All discharges must be piped to a safe place.

**WATER COLUMN OR GAGE GLASS** clean systems only—open drain quickly to vent small quantity of water. Water level should return quickly when valve is closed. Caution—All discharges must be piped to a safe place.

**LOW WATER FUEL CUT-OFF**—drain float chamber while boiler is running. This should interrupt the circuit and stop burner. Caution—All discharges must be piped to a safe place.

**PUMP AND SYSTEM**—check pump/return operation, leaky packing. Examine traps, check valves, making flow valves, expansion or condensate tank, and other parts of system.

**BURNER OPERATION** — if burner starts with a puff or operates roughly, call your service men at once!

**STOKER, OIL OR GAS BURNER AND CONTROLS**—The stoker, oil or gas burner and all operating and protective controls should be thoroughly checked at least once every three months by a competent service organization. See manufacturer's instructions. Record service dates above.

**UNUSUAL CONDITIONS SHOULD BE REPORTED TO THE COMPANY'S BRANCH OFFICE OR INSPECTOR AT ONCE.**